



Push-On Fitting Tool

Cut Hose

Built-in cutter slices through 1/4"- 3/4" ID reinforced push-on hose without fraying.

1. Retract the cutter, place the hose in the cutter area. (Fig. 1)
2. Pull the handle cutting the hose to desired length.
3. Remove hose from cutter area.

Hose is cut to length.




Figure 1

Assemble Fitting

These instructions are written for use with the flat plastic disc.

1. Place hose under the cam handle leaving hose extended to the proper mark on sticker as determined by hose size.
2. Align the hose end with the appropriate mark on the label.
3. Push cam handle forward, locking the hose in place. (Fig. 2)
4. Place barbed end of fitting snug against hose end.
5. Push slide handle forward, pressing the nose against the fitting, until the fitting is seated against the yellow plastic ring. (Fig. 3)
6. Retract slide handle.
7. Release cam handle.

Assembly is now ready for use.




Figure 2




Figure 3



CAUTION: Push-on fittings will properly grip push-on hose only when pushed all the way in, with the cut end of the hose completely concealed by the plastic cap.

Dixon®

800 High Street • Chestertown, MD 21620

ph: 877.963.4966 • 800.283.4966 • fx: 410.778.4702

dixonvalve.com

